

INSTALLATION INSTRUCTIONS

The best installation option is to install shelving securely into wall studs. We include the hardware for wall stud installation only, and assume no liability for any other installation method. Should your needs require installation into drywall, you can purchase heavy-duty metal hollow wall anchors or get advice from a hardware specialist.

1. Using a level, draw a horizontal pencil line on the wall marking the desired location of the bottom of the shelf.
2. Using a level, draw a vertical line down from the shelf line marking the center of the desired location for each corbel.
3. Place the side of the corbel flush on the wall with the top of the corbel touching the shelf line and the back touching the vertical line (see diagram 1). With a pencil, mark the drilling location for the screws at the top of the keyhole slot. Each corbel requires two screws to install securely.
4. Drill 3/32" holes in marked locations and install screws provided, leaving heads exposed approximately 1/2" from the wall (see diagram 2).
5. Place corbel over the screw heads and slide it down until secure. Adjust the screws in or out as needed until corbel is snug against the wall. Repeat for other corbel.
6. The shelf rests on top of the two corbels. For added stability, hammer a small finishing nail through the top of the shelf into each corbel. Countersink the nail. It is recommended that the shelf be pre-drilled for the finishing nail.

Mounting Diagrams

